
Software & Service for Practical Materials Innovation






# **Matplus EDA®**





- ✓ Example using Oracle Virtual Box
  - Import OVA Appliance


- Start the appliance
  - Ubuntu Linux Server
  - Headless, No GUI







✓ Set Port Forwarding Rules






- ✓ Option: Configure HTTPS if the machine shall be used as a server in a network
- ✓ Call script "eda-enable-https.sh" (included in PATH)
- ✓ This script expects certificate (cert.pem) and private key (cert.key) at /home/matdb/ssl folder
- ✓ EDA will then listen to port 443

Note: MobaXterm is a free software which facilitates working with the EDA console and also provides a SCP functionality

## Access EDA from your favourite browser




- ✓ Use <a href="http://localhost">https://servername</a>
- ✓ The system tells you initially that there is no license attached







- ✓ Example using vmware
  - Import our OVA Appliance
  - Start the appliance as
    - Ubuntu Linux LTS Server
    - Headless, No GUI
  - Ports 22, 80, 443 are open



### **Network Configuration of VA 1**



```
#file: /etc/hosts
echo "Your IP HOSTNAME" >> /etc/hosts
#file: /etc/hostname
echo "HOSTNAME" > /etc/hostname
#file: /etc/netplan/00-installer-config.yaml
This file must be updated inplace.
# Check the current network interfaces of your server
sudo ip link show
                ~# sudo ip link show
1: lo: <LOOPBACK,UP,LOWER_UP> mtu 65536 qdisc noqueue state UNKNOWN mode DEFAULT group default qlen
   Ink/loopback 00:00:00:00:00:00 brd 00:00:00:00:00:00
        <BROADCAST, MULTICAST> mtu 1500 qdisc noop state DOWN mode DEFAULT group default qlen 1000
  docker0: <NO-CARRIER,BROADCAST,MULTICAST,UP> mtu 1500 qdisc noqueue state DOWN mode DEFAULT group
```

In this example the second decice is your interface to be configured.

# **Network Configuration VA 2**



#### Step 1: create copy of origin file:

cp /etc/netplan/00-installer-config.yaml /etc/netplan/00-installer-config.yaml.old

#### Step 2: edit the content to look like this prepared sample

#### **Step 3: apply configuration change and reboot**

netplan apply reboot (reboot machine using ACPI Shutdown or external VMWare control)

# **Create Certificate Signing Request**



### In order to get a certificate

```
Login to the server as matdb.

openssl req -new \
-newkey rsa:2048 -nodes -keyout ~/ssl/cert.key \
-out ~/AHERSRVLNX39.csr \
-subj "/C=DE/ST=XY/L=Wuppertal/0=Matplus GmbH/OU=IT/CN=yourdomain.com"
```



- ✓ Configure HTTPS if the machine shall be used as a server in a network
- ✓ Call script
  - sudo eda-enable-https.sh (included in PATH)
- This script expects certificate (cert.pem) and private key (cert.key) at /home/matdb/ssl folder
- ✓ EDA will then listen to port 443

#### Note:

MobaXterm is a free software which facilitates working with the EDA headless console and also provides a SCP functionality

Thank you!



### **Uwe Diekmann**

### **Matplus GmbH**

Hofaue 55 D-42103 Wuppertal

Tel: + 49 (0)202 2978978 0 Fax + 49 (0)202 2978978 9

www.matplus.eu contact@matplus.eu

